



TEG2000 Test Board

Revision v.13

Exported on 2024-04-18

Online version of this document:

<https://wiki.trenz-electronic.de/display/PD/TEG2000+Test+Board>

1 Table of Contents

1	Table of Contents	2
2	Table of Figures	3
3	Table of Tables	4
4	Overview	6
4.1	Key Features	6
4.2	Revision History	6
4.3	Release Notes and Know Issues	6
4.4	Requirements	7
4.4.1	Software	7
4.4.2	Hardware	7
4.5	Content	8
4.5.1	Design Sources	8
4.5.2	Prebuilt	8
4.5.3	Download	9
5	Design Flow & Launch	10
6	System Design	11
6.1	HDL Sources	11
6.2	Constraints	12
6.2.1	Basic module constraints	12
7	Additional Software	14
8	App. A: Change History and Legal Notices	15
8.1	Document Change History	15
8.2	Legal Notices	15
8.3	Data Privacy	15
8.4	Document Warranty	15
8.5	Limitation of Liability	15
8.6	Copyright Notice	16
8.7	Technology Licenses	16
8.8	Environmental Protection	16
8.9	REACH, RoHS and WEEE	16

2 Table of Figures

3 Table of Tables

Table 1: Design Revision History	6
Table 2: Known Issues.....	6
Table 3: Software	7
Table 4: Hardware Modules	7
Table 5: Hardware Carrier.....	7
Table 6: Design sources	8
Table 7: Prebuilt files (only on ZIP with prebuilt content)	8
Table 8: Document change history.	15

4 Overview

Refer to <http://trenz.org/teg2000-info> for the current online version of this manual and other available documentation.

This page describes briefly how to generate the fpga configuration file (Bitstream/cfg file) from the blink-example and how to program the FPGA. For a more detailed description of the tools follow the Quick start section of [colognechip ug1002¹](#).

4.1 Key Features

- USB(JTAG/UART)
- LED

4.2 Revision History

Date	Project Built	Authors	Description
2024-04-15	TEG2000-test-board-cc-toolchain-win-trenz_20240415.zip	Waldemar Hanemann	<ul style="list-style-type: none"> • initial release

Table 1: Design Revision History

4.3 Release Notes and Know Issues

Issues	Description	Workaround	To be fixed version
No known issues	---	---	---

Table 2: Known Issues

¹ <https://www.colognechip.com/docs/ug1002-toolchain-install-latest.pdf>

4.4 Requirements

4.4.1 Software

Software	Version	Note
Yosys	0.37+ 39	needed for RTL synthesis
GateMate EasyConvert Place&Route	2024. 02-00 1	needed for implementation
openFPGALoader	v.0.1 1.0	needed for loading bitstream into FPGA

Table 3: Software

4.4.2 Hardware

Design supports following modules:

Module Model	Board Part Short Name	PCB Revision Support	DDR	QSPI Flash	EMMC	Others	Notes
TEG2000-01 -P001*	--	REV01	--	16MB	--		

Table 4: Hardware Modules

*used as reference

Design supports following carriers:

Carrier Model	Notes
TE0703*	We only support TE0703 up until now.

Table 5: Hardware Carrier

*used as reference

4.5 Content

4.5.1 Design Sources

Type	Location	Notes
Toolchain	<project folder>\bin	script-based tools for synthesis, implementation, bitfile generation and programming
fpga project	<project folder>\workspace\blink\log <project folder>\workspace\blink\net <project folder>\workspace\blink\sim <project folder>\workspace\blink\src	.bat scripts can be used for synthesis & implementation & programming

Table 6: Design sources

4.5.2 Prebuilt

File	File-Extension	Description
Constraint-File	*.ccf	FPGA pin constraint for pin-location, naming, input-output setting etc.
Design source-files	*.v , *.vhd	hdl design files describing the fpga functional description and I/O signals
Config File	*.cfg	Config File Data for FPGA. Comments included.
BIT-File	*.bit	FPGA (PL Part) Configuration File

Table 7: Prebuilt files (only on ZIP with prebuilt content)

4.5.3 Download

Reference Design is available on:

- [TEG2000 "Test Board" Reference Design²](#)

It contains the **tools**, the example project **blink** and several other sample projects(those are not documented here).

² https://shop.trenz-electronic.de/Download/?path=Trenz_Electronic/Modules_and_Module_Carriers/4x5/TEG2000/Reference_Design

5 Design Flow & Launch

1. After downloading the test design go into the directory <project folder>\workspace\blink\
2. On Windows you can now run the *.bat scripts.
3. Run synth.bat
4. Run impl.bat
5. Connect the Board (TEG2000 + TE0703 carrier) to power and USB, see [Getting started](#)³.
6. Run flash.bat to program the on-board qspi flash
7. Press reset, the green LED D2 should be blinking

³ <https://wiki.trenz-electronic.de/display/PD/TEG2000+Getting+Started>

6 System Design

6.1

HDL Sources

The design source files exist in verilog and in vhd.

blink.vhd

```
library ieee;
use ieee.std_logic_1164.all;
use ieee.numeric_std.all;

entity blink is
  port (
    clk : in std_logic;
    rst : in std_logic;
    led : out std_logic
  );
end entity;

architecture rtl of blink is

  component CC_PLL is
    generic (
      REF_CLK      : string; -- reference input in MHz
      OUT_CLK      : string; -- pll output frequency in MHz
      PERF_MD      : string; -- LOWPOWER, ECONOMY, SPEED
      LOW_JITTER   : integer; -- 0: disable, 1: enable low jitter mode
      CI_FILTER_CONST : integer; -- optional CI filter constant
      CP_FILTER_CONST : integer -- optional CP filter constant
    );
    port (
      CLK_REF      : in  std_logic;
      USR_CLK_REF  : in  std_logic;
      CLK_FEEDBACK : in  std_logic;
      USR_LOCKED_STDY_RST : in  std_logic;
      USR_PLL_LOCKED_STDY : out std_logic;
      USR_PLL_LOCKED : out std_logic;
      CLK0         : out std_logic;
      CLK90        : out std_logic;
      CLK180       : out std_logic;
      CLK270       : out std_logic;
      CLK_REF_OUT  : out std_logic
    );
  end component;

  signal clk0 : std_logic;
  signal counter : unsigned(26 downto 0);

begin
```

```

socket_pll : CC_PLL
generic map (
    REF_CLK          => "10.0",
    OUT_CLK          => "100.0",
    PERF_MD          => "ECONOMY",
    LOW_JITTER       => 1,
    CI_FILTER_CONST  => 2,
    CP_FILTER_CONST  => 4
)
port map (
    CLK_REF          => clk,
    USR_CLK_REF      => '0',
    CLK_FEEDBACK     => '0',
    USR_LOCKED_STDY_RST => '0',
    USR_PLL_LOCKED_STDY => open,
    USR_PLL_LOCKED  => open,
    CLK0             => clk0,
    CLK90            => open,
    CLK180           => open,
    CLK270           => open,
    CLK_REF_OUT      => open
);

process(clk0)
begin
    if rising_edge(clk0) then
        if rst = '0' then
            counter <= (others => '0');
        else
            counter <= counter + 1;
        end if;
    end if;
end process;

led <= counter(26);

end architecture;

```

6.2 Constraints

6.2.1 Basic module constraints

blink.ccf

```

## blink.ccf
#
# Date: 2022-10-21
#
# Format:
# <pin-direction> "<pin-name>" Loc = "<pin-location>" | <opt.-constraints>;
#

```

```

# Additional constraints can be appended using the pipe symbol.
# Files are read line by line. Text after the hash symbol is ignored.
#
# Available pin directions:
#
# Pin_in
#   defines an input pin
# Pin_out
#   defines an output pin
# Pin_inout
#   defines a bidirectional pin
#
# Available pin constraints:
#
# SCHMITT_TRIGGER={true,false}
#   enables or disables schmitt trigger (hysteresis) option
# PULLUP={true,false}
#   enables or disables I/O pullup resistor of nominal 50kOhm
# PULLDOWN={true,false}
#   enables or disables I/O pulldown resistor of nominal 50kOhm
# KEEPER={true,false}
#   enables or disables I/O keeper option
# SLEW={slow,fast}
#   sets slew rate to slow or fast
# DRIVE={3,6,9,12}
#   sets output drive strength to 3mA..12mA
# DELAY_OBF={0..15}
#   adds an additional delay of n * nominal 50ps to output signal
# DELAY_IBF={0..15}
#   adds an additional delay of n * nominal 50ps to input signal
# FF_IBF={true,false}
#   enables or disables placing of FF in input buffer, if possible
# FF_OBF={true,false}
#   enables or disables placing of FF in output buffer, if possible
# LVDS_BOOST={true,false}
#   enables increased LVDS output current of 6.4mA (default: 3.2mA)
# LVDS_TERM={true,false}
#   enables on-chip LVDS termination resistor of nominal 100Ohm, in output mode
only
#
# Global IO constraints can be set with the default_GPIO statement. It can be
# overwritten by individual settings for specific GPIOs, e.g.:
# default_GPIO | DRIVE=3; # sets all output strengths to 3mA, unless
overwritten
#

Pin_in   "clk"  Loc = "IO_SB_A8" | SCHMITT_TRIGGER=true;
Pin_in   "rst"  Loc = "IO_EB_B0"; # SW3
Pin_out  "led"  Loc = "IO_SB_B4"; # D1

```

7 Additional Software

No additional software is needed.

8 App. A: Change History and Legal Notices

8.1 Document Change History

To get content of older revision go to "Change History" of this page and select older document revision number.

Date	Document Revision	Authors	Description
 2024-04-16	v.13 (see page 5)	Waldemar Hanemann⁴	<ul style="list-style-type: none"> initial release blinky
--	all	Waldemar Hanemann⁵	--

Table 8: Document change history.

8.2 Legal Notices

8.3 Data Privacy

Please also note our data protection declaration at <https://www.trenz-electronic.de/en/Data-protection-Privacy>

8.4 Document Warranty

The material contained in this document is provided “as is” and is subject to being changed at any time without notice. Trenz Electronic does not warrant the accuracy and completeness of the materials in this document. Further, to the maximum extent permitted by applicable law, Trenz Electronic disclaims all warranties, either express or implied, with regard to this document and any information contained herein, including but not limited to the implied warranties of merchantability, fitness for a particular purpose or non infringement of intellectual property. Trenz Electronic shall not be liable for errors or for incidental or consequential damages in connection with the furnishing, use, or performance of this document or of any information contained herein.

8.5 Limitation of Liability

In no event will Trenz Electronic, its suppliers, or other third parties mentioned in this document be liable for any damages whatsoever (including, without limitation, those resulting from lost profits, lost data or business interruption) arising out of the use, inability to use, or the results of use of this document, any documents

⁴ <https://wiki.trenz-electronic.de/display/~w.hanemann>

⁵ <https://wiki.trenz-electronic.de/display/~w.hanemann>

linked to this document, or the materials or information contained at any or all such documents. If your use of the materials or information from this document results in the need for servicing, repair or correction of equipment or data, you assume all costs thereof.

8.6 Copyright Notice

No part of this manual may be reproduced in any form or by any means (including electronic storage and retrieval or translation into a foreign language) without prior agreement and written consent from Trenz Electronic.

8.7 Technology Licenses

The hardware / firmware / software described in this document are furnished under a license and may be used /modified / copied only in accordance with the terms of such license.

8.8 Environmental Protection

To confront directly with the responsibility toward the environment, the global community and eventually also oneself. Such a resolution should be integral part not only of everybody's life. Also enterprises shall be conscious of their social responsibility and contribute to the preservation of our common living space. That is why Trenz Electronic invests in the protection of our Environment.

8.9 REACH, RoHS and WEEE

REACH

Trenz Electronic is a manufacturer and a distributor of electronic products. It is therefore a so called downstream user in the sense of REACH⁶. The products we supply to you are solely non-chemical products (goods). Moreover and under normal and reasonably foreseeable circumstances of application, the goods supplied to you shall not release any substance. For that, Trenz Electronic is obliged to neither register nor to provide safety data sheet. According to present knowledge and to best of our knowledge, no SVHC (Substances of Very High Concern) on the Candidate List⁷ are contained in our products. Furthermore, we will immediately and unsolicited inform our customers in compliance with REACH - Article 33 if any substance present in our goods (above a concentration of 0,1 % weight by weight) will be classified as SVHC by the European Chemicals Agency (ECHA)⁸.

RoHS

Trenz Electronic GmbH herewith declares that all its products are developed, manufactured and distributed RoHS compliant.

WEEE

Information for users within the European Union in accordance with Directive 2002/96/EC of the European Parliament and of the Council of 27 January 2003 on waste electrical and electronic equipment (WEEE).

Users of electrical and electronic equipment in private households are required not to dispose of waste electrical and electronic equipment as unsorted municipal waste and to collect such waste electrical and electronic equipment separately. By the 13 August 2005, Member States shall have ensured that systems are set up allowing final holders and distributors to return waste electrical and electronic equipment at least free


⁶ <http://guidance.echa.europa.eu/>

⁷ <https://echa.europa.eu/candidate-list-table>

⁸ <http://www.echa.europa.eu/>

of charge. Member States shall ensure the availability and accessibility of the necessary collection facilities. Separate collection is the precondition to ensure specific treatment and recycling of waste electrical and electronic equipment and is necessary to achieve the chosen level of protection of human health and the environment in the European Union. Consumers have to actively contribute to the success of such collection and the return of waste electrical and electronic equipment. Presence of hazardous substances in electrical and electronic equipment results in potential effects on the environment and human health. The symbol consisting of the crossed-out wheeled bin indicates separate collection for waste electrical and electronic equipment.

Trenz Electronic is registered under WEEE-Reg.-Nr. DE97922676.

 2019-06-07